# The Sparse Fourier Transform: Applications

Haitham Hassanieh and Dina Katabi





# Fourier Transform Is Used Everywhere





**Medical Imaging** 





DNA Sequencing



**Oil Exploration** 

# Can we use Sparse Fourier Transform?





Sparse Fourier Transform: compute the Fourier transform in sublinear time faster than FFT.

**Faster Acquisition** 

**Faster Computation** 

# Sparse Fourier Transform Theory


- For a signal of size n with k large frequencies
- Run Time Complexity
  - Exactly sparse:  $O(k \log n)$
  - Approx. sparse:  $O(k \log(n) \log(n/k))$
- Faster Computation

- Sampling Complexity (Average Case)
  - Exactly sparse: O(k) samples
  - Approx. sparse:  $O(k \log(n))$  samples


Faster Acquisition

# Does it work in practice?

# **Applications of Sparse FFT**




# **Applications of Sparse FFT**



# **GPS**



#### GPS consumes a lot of power




H. Hassanieh, F. Adib, D. Katabi, & P. Indyk, Faster GPS via Sparse Fourier Transform MOBICOM'12

# **GPS**




GPS consumes a lot of power




# Can we use sparse FFT?

H. Hassanieh, F. Adib, D. Katabi, & P. Indyk, Faster GPS via Sparse Fourier Transform MOBICOM'12


How Does GPS Work?



How Does GPS Work?





distance = propagation delay × speed of light






Code arrives shifted by propagation delay








Spike determines the delay

# **Convolution** in Time




# Multiplication in Frequency

$$O(n^2)$$


 $O(n \log n)$ 

n: Number of samples in the code

# **GPS Using FFT**




# **GPS** Using FFT



Each stage takes  $O(n \log n)$ 

need to reduce complexity of both stages

# **GPS** Using FFT



FFT Stage

**IFFT Stage** 

Sparse IFFT

# Sparse IFFT for GPS


#### 1- Binning

Divide output into a few bins

#### 2- Estimation


Estimate the largest coefficient in the largest bin

#### **Original Output**



# How to Do Binning Efficiently?

### Sub-sampling input → Aliasing of output




# How to do Estimation Efficiently?

Out of the samples in the large bin, which one is the spike?



The spike is the sample that has the maximum correlation




# Sparse IFFT for GPS


- n is number of samples
- l samples per bin  $\rightarrow n/l$  bins

Binning: 
$$n/l \log(n/l)$$


Estimation: 
$$l \times n$$


$$l = \sqrt{\log n} \qquad \longrightarrow \qquad O(n\sqrt{\log n})$$





Output is not sparse
Cannot Use Sparse FFT






**Subsampled FFT** 

Sparse IFFT

Need only few samples of FFT output


IFFT samples its input



**Subsampled FFT** 

**Sparse IFFT** 


FFT and IFFT are dual of each other



**Subsampled FFT** 

**Sparse IFFT** 

Aliasing input FFT Subsampling IFFT Aliasing output




# **Subsampled FFT**

# $O(n\sqrt{\log n})$

#### **Sparse IFFT**

$$O(n\sqrt{\log n})$$

# Experiments





Traces are collected both US and Europe


• Gain =  $\frac{\text{Number Operations using FFT}}{\text{Number Operations using Sparse FFT}}$ 

Sparse FFT provides a gain of 2.2x



Significant reduction in power

# **Applications of Sparse FFT**




# Spectrum Shortage

- FCC: spectrum crunch started in 2013
- Increasing wireless demand
  - → But no more spectrum availability

The iPhone 4 demo failed at Steve Jobs's keynote due to wireless congestion.


Jobs's reaction: "If you want to see the demos, shut off your laptops, turn off all these MiFi base stations, and put them on the floor, please."



H. Hassanieh, L. Shi, O. Abari, E. Hamed & D. Katabi, *GHz-Wide Sensing and Decoding Using the Sparse Fourier Transform*, **INFOCOM'12** 


# Spectrum Shortage

#### But at any time, most of the spectrum is unused




Solution: Sense to find unused bands → Use them! Challenge: How to find unused bands with dynamic spectrum usage?

### **GHz Spectrum Sensing in Real-time**




## Real-time GHz Spectrum Sensing is Difficult

# Today: Sequential sensing with MHz Sampling




- Cheap, low power
- Miss important signals


# Ideally: Real-time sensing with GHz Sampling




- Capture all signals
- Costly, high power, and effectively impractical

#### Real-time GHz Spectrum Sensing is Difficult






# Ideally: Real-time sensing with GHz Sampling



#### Goal:

Real-time GHz sensing with MHz sampling

#### Leverage the Spectrum Sparsity




# **Use Sparse FFT**

#### 1- Binning


Divide spectrum into a few bins


#### 2- Estimation

Estimate the large coefficients in each non-empty bin




value of bin = 
$$\sum \hat{\mathbf{x}}_f$$







Bin multiple time using co-prime sub-sampling

Same frequencies don't collide in both






Identify isolated freq. in one binning and subtract them from the other; and iterate ...




Output


**Result:** 




Identify isolated freq. in one binning and subtract them from the other; and iterate ...




Output
Result:




Identify isolated freq. in one binning and subtract them from the other; and iterate ...





Output Result:



















Identify isolated freq. in one binning and subtract them from the other; and iterate ...





Identify isolated freq. in one binning and subtract them from the other; and iterate ...



**Binning** 

**Estimation** 

Repeat binning after shifting the signal in time by a time shift  $\tau$ 

x(t)

$$x(t-\tau)$$

#### **Freq-Domain**

$$X(f)e^{-j\theta}$$

Phase Rotation : 
$$\theta = \frac{2\pi f \tau}{N} \rightarrow f = \frac{N\theta}{2\pi \tau}$$

#### GHz Receiver Using the Sparse FFT


Built a receiver that can capture GHz of spectrum using a total of 150 MHz sampling rate



#### GHz Receiver Using the Sparse FFT

Cambridge, MA January 15 2013


Occupancy from 2GHz to 3GHz (10 ms FFT window)



#### GHz Receiver Using the Sparse FFT


Cambridge, MA January 15 2013

Occupancy from 2GHz to 3GHz (10 ms FFT window)





SFFT enables realtime GHz sensing for low-power portable devices

# **Applications of Sparse FFT**



#### 0.75-Million Point Sparse FFT Chip





|               | Traditional FFTs             | Sparse FFT              |
|---------------|------------------------------|-------------------------|
|               | [ISSCC'11, JSSC'08, JSSC'12] | [ISSCC'14]              |
| Size          | ≈ Thousand Point             | ≈ Million Point         |
| Energy/Sample | 17.2pJ                       | 0.4pJ (40x lower power) |

O. Abari, E. Hamed, H. Hassnanieh, A. Agarwal, D. Katabi, A. Chandrakasan, V. Stojanovic, A 0.75 Million-Point Fourier Transform Chip for Frequency Sparse Signals ISSCC'14

# **Applications of Sparse FFT**

