



Laser Speckle Photography for Surface Tampering Detection

YiChang Shih Abe Davis Frédo Durand William T. Freeman

Samuel W. Hasinoff,



Before image





Before image





Before image

After image








Before image

After image

Goal: detect the touched region

Security certification





Safe box Footprint


Challenging problem

• The difference are minor and invisible



A lab wall (rock sheet)


Touched by hand



Difference between before and after images (scale to [0 1]), cannot see anything

Related work: paper authentication

- Certify whether the document is original [Pappu et al 2002][Buchanan et al 2005]
- Use the micro-structure as signatures



Photographed by electronic microscope



Ingenia Techology

Related work: forensic technology

- Rely on bio footprint, eg. blood, perspiration
- Laborious works



Foot print



Luminol (blood)



Fingerprint powder


Problem statement


• Input: before and after images

Output: the region that has been touched

Automatic, fast, work on various materials

Key idea: laser speckle





Coherent light causes interference pattern


Laser speckle

The coherent light causes granular patterns






Without coherent light




With coherent light (laser speckle)

Tampering detection




Before touch the surface



After touch the surface, the interference patterns are changed

Hardware overview

- Camera
- Laser scanner
- Controller





Issues that need to be concerned


Compute the similarity map


Camera settings

Viewpoint alignment










Identifying the tampered regions

- The speckle changes are local
- We use normalized cross correlation (NCC)



Camera settings

- Aperture cannot be too large or too small
- f/6.7 works best experimentally




Aperture too large: low contrast

Too **small**: no high-frequency, lost locality

Viewpoint registration


Challenge: speckle is very sensitive to viewpoint change
Scattered laser field



Very tight accuracy goal

Require the distance between the two

viewpoints < 1mm



Our approach: two-step alignment


- Step 1: vision-based alignment
 - tolerance ~10 mm

- Step 2: speckle-based alignment
 - tolerance < 1mm

Coarse alignment by scene features

- Based on parallel tracking and mapping (PTAM)
- Feedbacks to guide user control
- A few minutes to reach the viewpoint with 3mm

accuracy



User interface


Fine alignment by speckles

Utilize the speckle sensitivity to viewpoint


Densely sample between [-5mm, 5mm]

Accurate to 0.5mm

Results



Touched by hand



Output: the touched region

Light-weight objects


A quarter on a card box (5.67g)



A card box




A quarter (5.67g)



Output: the detected tampered region


More materials




Plastic case

Indoor scene

Touched by a finger



Curved surface



Objects to detect

The detected tampering

Textured surface



Objects to detect




The detected tampering

Comparisons to forensic techniques

Touched by a finger

Shiny surface


Rough surface



Objects to detect Our speckle-based method

Fingerprint powder

With gloves



Our speckle-based method

Fingerprint powder

Using the system

• See the video!

Demo at CVPR12

Take a reference laser speckle image



Touch the surface








Take an "after" laser speckle image correlation reveals



Normalized the tampered area





Conclusion: seeing invisibles

- Seeing the invincible difference between two images
- Key idea: using laser speckle images
- Viewpoint alignment with high accuracy



A lab wall

Touched by hand



Output: the touched region

Acknowledgements

 We thank MicroVision for donation of equipment, and acknowledge gifts from Microsoft Research and Texas Instruments, and funding from NSF CGV No.1111415.









Conclusion: seeing invisibles

- Seeing the invisible difference between two images
- Key idea: using laser speckle images
- Viewpoint alignment with high accuracy



A lab wall

Touched by hand

0.8 0.6 0.4 0.2

Output: the touched region